

# Photographic Dynamic Range versus ISO Setting

(DX) indicates DX crop (APS-C) indicates APS-C crop, and (FF) indicates FF crop. (ES) indicates electronic shutter. (p) indicated preliminary data

Open symbols indicate values outside the normal analog range

Triangle up indicates scaling, triangle down indicates noise reduction, and diamond indicates both

- FujiFilm X100F
- FujiFilm X-Pro3
- Leica M (Typ 240)
- Leica M Monochrom

